

		Canon Camera Terminal Type		Required Adapters		
		USB-C	USB-Micro B (5-Pin)			
		Models	EOS RP , EOS R50 , EOS R100 , EOS M6 Mark II	EOS Rebel T8i , EOS Rebel SL3 , EOS 90D , EOS M50 Mark II , EOS M200		
iPad* Terminal Type *iPadOS 15 Compatible Models only	USB-C	iPad Pro 11-inch (1st generation or later)	USB-C to USB-C Data Cable	USB-Micro B (5-Pin) to USB-C Data Cable	No Adaptor Needed	
		iPad Pro 12.9-inch (3rd generation or later)				
		iPad (10th generation)				
		iPad Air (4th generation or later)				
		iPad mini (6th generation)				
	Lightning	iPad Pro 9.7-inch	USB-C to USB-A Data Cable	USB-Micro B (5-Pin) to USB-A Data Cable		Apple Lightning to USB 3 Camera Adapter
		iPad Pro 10.5-inch				
		iPad Pro 12.9-inch (1st & 2nd generation)				
		iPad (5th - 9th generation)				
		iPad Air 2				
		iPad Air (3rd generation)				
		iPad Mini 4				
		iPad Mini (5th generation)				

NOTES:

If your Canon camera model is not listed above, check your user manual or Canon's website for your camera's interface terminal type. You may also use tether-tools.com to determine which cable is compatible with your particular camera model and iPad terminal type (USB-C or Lightning. Lightning will use a USB-A and adapter).

If your iPad model is not listed above, it **does not** support iPadOS 15 or later and is not compatible with the latest version of TouchMD SNAP/SNAP Pro.

When purchasing your cable, be sure to select the desired color, style, and length.

We recommend visiting tether-tools.com for cables 15ft or longer, or for other camera tethering accessories.