

		Canon Camera Terminal Type		Required Adapters		
		USB-C	USB-Micro B (5-Pin)			
		<b>Models</b>	<a href="#">EOS RP</a> , <a href="#">EOS R50</a> , <a href="#">EOS R100</a> , <a href="#">EOS M6 Mark II</a>	<a href="#">EOS Rebel T8i</a> , <a href="#">EOS Rebel SL3</a> , <a href="#">EOS 90D</a> , <a href="#">EOS M50 Mark II</a> , <a href="#">EOS M200</a>		
<b>iPad* Terminal Type</b>  *iPadOS 15 Compatible Models only	<b>USB-C</b>	iPad Pro 11-inch (1st generation or later)	<a href="#">USB-C to USB-C Data Cable</a>	<a href="#">USB-Micro B (5-Pin) to USB-C Data Cable</a>	No Adaptor Needed	
		iPad Pro 12.9-inch (3rd generation or later)				
		iPad (10th generation)				
		iPad Air (4th generation or later)				
		iPad mini (6th generation)				
	<b>Lightning</b>	iPad Pro 9.7-inch	<a href="#">USB-C to USB-A Data Cable</a>	<a href="#">USB-Micro B (5-Pin) to USB-A Data Cable</a>		<a href="#">Apple Lightning to USB 3 Camera Adapter</a>
		iPad Pro 10.5-inch				
		iPad Pro 12.9-inch (1st & 2nd generation)				
		iPad (5th - 9th generation)				
		iPad Air 2				
		iPad Air (3rd generation)				
		iPad Mini 4				
		iPad Mini (5th generation)				

**NOTES:**

If your Canon camera model is not listed above, check your user manual or Canon's website for your camera's interface terminal type. You may also use [tether-tools.com](http://tether-tools.com) to determine which cable is compatible with your particular camera model and iPad terminal type (USB-C or Lightning. Lightning will use a USB-A and adapter).

If your iPad model is not listed above, it **does not** support iPadOS 15 or later and is not compatible with the latest version of TouchMD SNAP/SNAP Pro.

When purchasing your cable, be sure to select the desired color, style, and length.

We recommend visiting [tether-tools.com](http://tether-tools.com) for cables 15ft or longer, or for other camera tethering accessories.