			Canon Camera Terminal Type		
			USB-C	**USB-Micro B (5-Pin)**	**Required Adaptors**
		Models	EOS RP, PowerShot G7 X Mark III, EOS M6 Mark II	EOS Rebel T8i, EOS Rebel SL3, EOS M200, EOS M50 Mark II, EOS 90D	
iPad* Terminal Type *iPadOS 15 Compatible Models Only*	**USB-C**	iPad Pro 11-inch (1st generation or later)	USB-C to USB-C Data Cable	USB Micro-B (5-Pin) to USB-C Data Cable	No Adaptor Needed
		iPad Pro 12.9-inch (3rd generation or later)			
		iPad (10th generation)			
		iPad Air (4th generation or later)			
		iPad mini (6th generation)			
	Lightning	iPad Pro 9.7-inch	USB-C to USB-A Data Cable	USB Micro-B (5-Pin) to USB-A Data Cable	Apple Lightning to USB 3 Camera Adapter
		iPad Pro 10.5-inch			
		iPad Pro 12.9-inch (1st & 2nd generation)			
		iPad (5th - 9th generation)			
		iPad Air 2			
		iPad Air (3rd generation)			
		iPad mini 4			
		iPad mini (5th generation)			

NOTES:
If your Canon camera model is not listed above, check your user manual or Canon's website for your camera's interface terminal type.
If your iPad model is not listed above, it does not support iPadOS 15 or later and is not compatible with the latest version of TouchMD SNAP.
When purchasing your cable, be sure to select the desired color, style and length.
We recommend visiting tethertools.com for cables 15ft or longer, or for other camera tethering accessories